

# Fitting the Woodwarm Rear Flue Adaptor

The Woodwarm Rear Flue Adaptor is designed to be bolted from the inside of the stove via 4 x M8 Set Screws sandwiching the back plate of the stove with a retaining ring to the body of the adaptor, an air tight seal must be made between the back of the stove and the rear flue adaptor.

The Woodwarm Rear Flue Adaptor is available in the following sizes for both the *Fireview* and the *Wildwood* Freestanding range:-

- 125mm (5 inch) 4kw, 4.5kw (4.5kw collar pre welded to the adaptor)
- 150mm (6 inch) 5kw, 6kw, 7kw, 8kw, 9kw, 12kw(S32)
- 178mm (7 inch) 10kw(S53), 12kw(S48), 14kw, 16kw, 20kw

